


PASCObot Spares Kit

PS-5094

What's included

**1 2× Hub**

Use the hub for attaching the PASCObot Wheels to a motor. Attach the hub to the spline of the High Speed Stepper Motor (PS-2976), Low Speed Stepper Motor (PS-2978), or any standard servo motor.

2 2× Screw, 4-40×1/4"

Use these screws for securing the hub to the spline of a stepper or servo motor.

3 8× Screw, 6-32×3/8"

Use these screws for securing the PASCObot Wheels (PS-3319) to the hub.

4 20× Screw, 4-40×7/15"

Use these screws for securing accessories to the PASCObot threaded holes.

5 2× Thumbscrew

Use the thumbscrew to secure the PASCObot top frame to the hold-down.

Technical Support

Need more help? Our knowledgeable and friendly Technical Support staff is ready to provide assistance with this or any other PASCO product.

Phone (USA) 1-800-772-8700 (Option 4)

Phone (International) +1 916 462 8384

Online pasco.com/support

Warranty, Copyright, and Trademarks

Limited Warranty

For a description of the product warranty, see the Warranty and Returns page at www.pasco.com/legal.

Copyright

This document is copyrighted with all rights reserved. Permission is granted to non-profit educational institutions for reproduction of any part of this manual, providing the reproductions are used only in their laboratories and classrooms, and are not sold for profit. Reproduction under any other circumstances, without the written consent of PASCO scientific, is prohibited.

Trademarks

PASCO and PASCO scientific are trademarks or registered trademarks of PASCO scientific, in the United States and/or in other countries. All other brands, products, or service names are or may be trademarks or service marks of, and are used to identify, products or services of, their respective owners. For more information visit www.pasco.com/legal.